

Quick Reference Guide

QUICK REFERENCE SHEET for B070-016-19, B070-016-19-IP, B072-008-1, B072-016-1 and B072-016-1-IP KVM Switches
Hotkey and OSD Operating Commands

Command	Hotkey Sequence	OSD Sequence	Description
Open the OSD	Press [Shift] , [Shift] keys	—	[Shift] , [Shift] is the default Hotkey Sequence. This can be switched to one of four options. (See below for details.)
Switch to Next Available Port	Press [Shift] , Plus [+] keys	<ul style="list-style-type: none"> • Open the OSD using the steps above • Navigate to the desired port and press the [Enter] key 	—
Switch to the Previous Port	Press [Shift] , Minus [-] keys	<ul style="list-style-type: none"> • Open the OSD using the steps above • Navigate to the desired port and press the [Enter] key 	—

To Change the Switch Hotkey:

1. Highlight the Hotkey option in the OSD General Settings menu.
2. Press **[Space]** to toggle through the various options.
3. When you've selected the desired Hotkey, simply exit the OSD. Pressing **[Enter]** is not required to activate your selection.

Notes:

4. **(SH-SH)**: This represents the **[Shift]** key. To access the OSD menu, press **[Shift]** twice. To access the next KVM in line, press **[Shift]**, then **[+]**. To access the previous KVM in line, press **[Shift]**, then **[-]**.
5. **(CL-CL)**: This represents the **[Ctrl]** key. To access the OSD menu, you can either press the left **[Ctrl]** key twice or you can press the right **[Ctrl]** key once and then the left **[Ctrl]** key. You can press either **[Ctrl]** key once and the **[+]** key to access the next KVM in line. You can press either **[Ctrl]** key once and the **[-]** key to access the previous KVM in line.
6. **(CLF11)**: This represents the **[Ctrl]** key and the **[F11]** key. To access the OSD menu, you press either **[Ctrl]** key and then **[F11]**. You can press either **[Ctrl]** key once and then **[+]** to access the next KVM in line. You can press either **[Ctrl]** key once and then **[-]** to access the previous KVM in line.
7. **(PRSCR)**: This represents the **[Print Screen]** key. To access the OSD menu, press **[Print Screen]**. When you select **[Print Screen]** as your Hotkey, the Port Selection Hotkey commands are deactivated, leaving the OSD main menu as the only way to switch to another port.



Tripp Lite World Headquarters

1111 W. 35th Street, Chicago, IL 60609 USA • (773) 869-1234
www.tripplite.com